

Ignition Coil

Part Series	Fit for vehicle	OEM NO./Part NO.
Ignition Coil	Toyota	90919-02164
Ignition Coil	Toyota	90919-02212
Ignition Coil	Toyota	90919-02215
Ignition Coil	Toyota	90919-02216
Ignition Coil	Toyota	90919-02217
Ignition Coil	Toyota	90919-02220
Ignition Coil	Toyota	90919-02228
Ignition Coil	Toyota	90919-02230
Ignition Coil	Toyota	90919-02234
Ignition Coil	Toyota	90919-02235
Ignition Coil	Toyota	90919-02236
Ignition Coil	Toyota	90919-02237
Ignition Coil	Toyota	90919-02238
Ignition Coil	Toyota	90919-02239
Ignition Coil	Toyota	90919-02240
Ignition Coil	Toyota	90919-02244
Ignition Coil	Toyota	90919-02245
Ignition Coil	Toyota	90919-02246
Ignition Coil	Toyota	90919-02247
Ignition Coil	Toyota	90919-02248
Ignition Coil	Toyota	90919-02250
Ignition Coil	Toyota	90919-02255
Ignition Coil	Toyota	90919-02260
Ignition Coil	Toyota	90919-02262
Ignition Coil	Toyota	90919-02266
Ignition Coil	Toyota	90919-A2002
Ignition Coil	Toyota	90919-C2001
Ignition Coil	Toyota	90919-C2003
Ignition Coil	Toyota	90919-C2005
Ignition Coil	Toyota	90919-C2006
Ignition Coil	Toyota	
Ignition Coil	Toyota	90919-02217
Ignition Coil	Toyota	90919-02227
Ignition Coil	Toyota	90919-02249
Ignition Coil	Toyota	90919-02258
Ignition Coil	Toyota	90919-02172
Ignition Coil	Toyota	90919-02229
Ignition Coil	Toyota	90919-02255
Ignition Coil	Toyota	90919-02256
Ignition Coil	Toyota	90919-02263

Ignition Coil	Toyota	90919-A2001
Ignition Coil	Toyota	90919-A2006
Ignition Coil	Toyota	90919-C2001
Ignition Coil	Toyota	90919-C2004
Ignition Coil	Toyota	90919-C2007
Ignition Coil	Toyota	90919-T2001
Ignition Coil	Toyota	90919-T2004
Ignition Coil	DAIHATSU Toyota	19070-B1020
Ignition Coil	Nissan	22448-2Y000
Ignition Coil	Nissan	22448-2Y005/MCP-2850
Ignition Coil	Nissan	22448-6N015/AIC-4004G
Ignition Coil	Nissan	22448-8H315/AIC-4001G
Ignition Coil	Nissan	22448-8J11C/AIC-3102N
Ignition Coil	Nissan	22448-8J115/AIC-3102G
Ignition Coil	Nissan	22448-31U01
Ignition Coil	Nissan	22448-31U05
Ignition Coil	Nissan	22448-AL615/AIC-3103G
Ignition Coil	Nissan	22448-CJ00A/0 221 604 020
Ignition Coil	Nissan	22448-ED800/0 221 604 014
Ignition Coil	Nissan	22448-JA10A/AIC-2409B
Ignition Coil	Nissan	22448-JN10A
Ignition Coil	Nissan	22433-59S10
Ignition Coil	Nissan	22448-1KT0A
Ignition Coil	Nissan	22448-2Y502
Ignition Coil	Nissan	22448-2Y700
Ignition Coil	Nissan	22448-7S015
Ignition Coil	Nissan	22448-AR215
Ignition Coil	Nissan	22448-AX001
Ignition Coil	Nissan	22448-EA000
Ignition Coil	Nissan Skyline	MCP-1840
Ignition Coil	Honda	30500-P0A-A01/CM1T-228
Ignition Coil	Honda	30500-P2A-J01/CM1T-231
Ignition Coil	Honda	30510-P73-A02/TC-08A
Ignition Coil	Honda	30520-P8E-A01
Ignition Coil	Honda	30520-PGK-A01
Ignition Coil	Honda	30520-PNA-007/099700-070
Ignition Coil	Honda	30520-PWA-003/CM11-109
Ignition Coil	Honda	30520-PWC-003/CM11-110
Ignition Coil	Honda	30520-R40-003/099700-147
Ignition Coil	Honda	30520-RB0-003/CM11-116
Ignition Coil	Honda	30520-RNA-A01
Ignition Coil	Honda	30521-PWA-003
Ignition Coil	Honda	2W93-12A366-BA
Ignition Coil	Honda Isuzu	8971363250
Ignition Coil	Honda	CM11-102
Ignition Coil	Mitsubishi	MD314582
Ignition Coil	Mitsubishi	MD314583

Fuel Injector Nozzle

Part Series	Fit for vehicle	OEM NO./Part NO.
Fuel Injector Nozzle	Toyota	23250-74200 / 2309-74200
Fuel Injector Nozzle	Toyota	23209-0A020
Fuel Injector Nozzle	Toyota	23209-0D040
Fuel Injector Nozzle	Toyota	23209-0D050
Fuel Injector Nozzle	Toyota	23209-0H060
Fuel Injector Nozzle	Toyota	23209-0t010
Fuel Injector Nozzle	Toyota	23209-03010
Fuel Injector Nozzle	Toyota	23209-11050
Fuel Injector Nozzle	Toyota	23209-11060
Fuel Injector Nozzle	Toyota	23209-11070
Fuel Injector Nozzle	Toyota	23209-11120
Fuel Injector Nozzle	Toyota	23209-11130
Fuel Injector Nozzle	Toyota	23209-13030
Fuel Injector Nozzle	Toyota	23209-15040
Fuel Injector Nozzle	Toyota	23209-16150
Fuel Injector Nozzle	Toyota	23209-16160
Fuel Injector Nozzle	Toyota	23209-20010
Fuel Injector Nozzle	Toyota	23209-21020
Fuel Injector Nozzle	Toyota	23209-21060
Fuel Injector Nozzle	Toyota	23209-22010
Fuel Injector Nozzle	Toyota	23209-22030
Fuel Injector Nozzle	Toyota	23209-22040
Fuel Injector Nozzle	Toyota	23209-22060
Fuel Injector Nozzle	Toyota	23209-22080
Fuel Injector Nozzle	Toyota	23209-22090
Fuel Injector Nozzle	Toyota	23209-22130
Fuel Injector Nozzle	Toyota	23209-28020
Fuel Injector Nozzle	Toyota	23209-28050
Fuel Injector Nozzle	Toyota	23209-28060
Fuel Injector Nozzle	Toyota	23209-28080
Fuel Injector Nozzle	Toyota	23209-29015
Fuel Injector Nozzle	Toyota	23209-45011

Fuel Injector Nozzle	Toyota	23209-46010
Fuel Injector Nozzle	Toyota	23209-46070
Fuel Injector Nozzle	Toyota	23209-46080
Fuel Injector Nozzle	Toyota	23209-46090
Fuel Injector Nozzle	Toyota	23209-50030
Fuel Injector Nozzle	Toyota	23209-62030
Fuel Injector Nozzle	Toyota	23209-66010
Fuel Injector Nozzle	Toyota	23209-70120
Fuel Injector Nozzle	Toyota	23209-74080
Fuel Injector Nozzle	Toyota	23209-74100
Fuel Injector Nozzle	Toyota	23209-74130
Fuel Injector Nozzle	Toyota	23209-74140
Fuel Injector Nozzle	Toyota	23209-74170
Fuel Injector Nozzle	Toyota	23209-74190
Fuel Injector Nozzle	Toyota	23209-74220
Fuel Injector Nozzle	Toyota	23209-75080-23209-79135
Fuel Injector Nozzle	Toyota	23209-79045
Fuel Injector Nozzle	Toyota	23209-79105-23250-75060
Fuel Injector Nozzle	Toyota	23209-36010
Fuel Injector Nozzle	Toyota	23250-0D050
Fuel Injector Nozzle	Toyota	23250-22030
Fuel Injector Nozzle	Toyota	23250-23020
Fuel Injector Nozzle	Toyota	23250-28030
Fuel Injector Nozzle	Toyota	23250-28090
Fuel Injector Nozzle	Toyota	23250-31020
Fuel Injector Nozzle	Toyota	23250-38020
Fuel Injector Nozzle	Toyota	23250-46131
Fuel Injector Nozzle	Toyota	23250-65010
Fuel Injector Nozzle	Toyota	23250-70120
Fuel Injector Nozzle	Toyota	23250-0A010
Fuel Injector Nozzle	Toyota	23250-0D030
Fuel Injector Nozzle	Toyota	23250-0P030
Fuel Injector Nozzle	Toyota	23250-0P050
Fuel Injector Nozzle	Toyota	23250-15010
Fuel Injector Nozzle	Toyota	23250-15030
Fuel Injector Nozzle	Toyota	23250-20020
Fuel Injector Nozzle	Toyota	23250-21040

Fuel Injector Nozzle	Toyota	23250-22080
Fuel Injector Nozzle	Toyota	23250-23209-79095
Fuel Injector Nozzle	Toyota	23250-28080
Fuel Injector Nozzle	Toyota	23250-31010-23209-39015
Fuel Injector Nozzle	Toyota	23250-31050
Fuel Injector Nozzle	Toyota	23250-31060-23209-39075
Fuel Injector Nozzle	Toyota	23250-36010
Fuel Injector Nozzle	Toyota	23250-46020-23209-49015
Fuel Injector Nozzle	Toyota	23250-46040-23209-49025
Fuel Injector Nozzle	Toyota	23250-50040
Fuel Injector Nozzle	Toyota	23250-50060
Fuel Injector Nozzle	Toyota	23250-62040
Fuel Injector Nozzle	Toyota	23250-74090-23209-79015
Fuel Injector Nozzle	Toyota	23250-74160
Fuel Injector Nozzle	Toyota	23250-74250
Fuel Injector Nozzle	Toyota	23250-75060-23209-79105
Fuel Injector Nozzle	Toyota	23250-75070-23209-79115
Fuel Injector Nozzle	Toyota	23250-75070
Fuel Injector Nozzle	Toyota	23250-75090-23209-79145
Fuel Injector Nozzle	Toyota	23250-75100-23209-79155
Fuel Injector Nozzle	Toyota	23250-76020-23209-79055
Fuel Injector Nozzle	Toyota	23250-97204
Fuel Injector Nozzle	Toyota	23250-97401
Fuel Injector Nozzle	Toyota	23250-97501
Fuel Injector Nozzle	Toyota	23250-28070
Fuel Injector Nozzle	Toyota / Mazda	195500-4450
Fuel Injector Nozzle	Toyota	1001-87F90
Fuel Injector Nozzle	Toyota	1001-87K80
Fuel Injector Nozzle	Nissan	16600-2Y915
Fuel Injector Nozzle	Nissan	16600-5L300
Fuel Injector Nozzle	Nissan	16600-35U01
Fuel Injector Nozzle	Nissan	16600-53J03
Fuel Injector Nozzle	Nissan	16600-JF00A
Fuel Injector Nozzle	Nissan	16600-JK00A
Fuel Injector Nozzle	Nissan	16600-5L300
Fuel Injector Nozzle	Nissan	16600-1S700 0Z800
Fuel Injector Nozzle	Nissan	16600-9S200 JS23-4

Fuel Injector Nozzle	Nissan	16600-73C00
Fuel Injector Nozzle	Nissan	A46-H02
Fuel Injector Nozzle	Nissan	FBJB101
Fuel Injector Nozzle	Nissan	FBJE100
Fuel Injector Nozzle	Nissan	16600-EN200
Fuel Injector Nozzle	Honda	16450-PPA-003
Fuel Injector Nozzle	Honda	16450-RAA-A01
Fuel Injector Nozzle	Honda	16450-RWC-A01
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-3020
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-3030
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-3040
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-3050
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-3110
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-3170
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-3310
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-3580
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-4370
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-4430
Fuel Injector Nozzle	Mitsubishi / Mazda	195500-4450
Fuel Injector Nozzle	Mitsubishi / Mazda	INP-772
Fuel Injector Nozzle	Mitsubishi / Mazda	INP-774
Fuel Injector Nozzle	Mitsubishi / Mazda	INP-781
Fuel Injector Nozzle	Mitsubishi	CDH100A
Fuel Injector Nozzle	Mitsubishi	CDH145
Fuel Injector Nozzle	Mitsubishi	CDH166
Fuel Injector Nozzle	Mitsubishi	CDH210
Fuel Injector Nozzle	Mitsubishi	CDH275
Fuel Injector Nozzle	Mitsubishi	E7T05073 DIM1000J
Fuel Injector Nozzle	Mitsubishi	E7T05074
Fuel Injector Nozzle	Mitsubishi	E7T05075
Fuel Injector Nozzle	Mitsubishi	MDH182 INP-062
Fuel Injector Nozzle	Mazda	297500-0460
Fuel Injector Nozzle	Mazda	297500-0540
Fuel Injector Nozzle	Mazda	297500-0790
Fuel Injector Nozzle	Mazda	L3K9-13-250A-E7T20171
Fuel Injector Nozzle	Ford	1F2E 9F593 B4A
Fuel Injector Nozzle	Ford	1L2E 9F593 D4A

Fuel Injector Nozzle	Ford	2C5E 9F593 A4A
Fuel Injector Nozzle	Ford	2M2E-9F593-A7B
Fuel Injector Nozzle	Ford	4L8E 9F593 A4A
Fuel Injector Nozzle	Ford	5C3E 9F593 DB
Fuel Injector Nozzle	Ford	F03E-A2B-2342466
Fuel Injector Nozzle	Ford	XR3E 9F593 A6B
Fuel Injector Nozzle	Ford	YR3E 9F593 A6A
Fuel Injector Nozzle	VW	037906031AA
Fuel Injector Nozzle	VW	037906031AL
Fuel Injector Nozzle	VW	0280150962
Fuel Injector Nozzle	BMW	0280150501
Fuel Injector Nozzle	BMW	0280150502
Fuel Injector Nozzle	Mercedes-Benz	0280155205 0000787023
Fuel Injector Nozzle	Mercedes-Benz	0280155828
Fuel Injector Nozzle	Mercedes-Benz	280156070
Fuel Injector Nozzle	Mercedes-Benz	280156146
Fuel Injector Nozzle	Subaru	JS27-1
Fuel Injector Nozzle	Subaru	16600-AA170
Fuel Injector Nozzle	Subaru	16611-AA521
Fuel Injector Nozzle	Subaru	195500-3910
Fuel Injector Nozzle	Subaru	16611-AA720
Fuel Injector Nozzle	Fiat	IWP-069
Fuel Injector Nozzle	Suzuki	JS28-1
Fuel Injector Nozzle	Chery	0280 155 964
		To be continued

Spark Plug / Oil Filter / Fuel Pump

Part Series	Fit for vehicle	OEM NO./Part NO.
Spark Plug	Toyota	90919-01191 / SK20HR11
Spark Plug	Toyota	90919-01253 / SC20HR11
Spark Plug	Toyota	90919-01247 / FK20HR11
Spark Plug	Toyota	90919-01249 / FK20HBR11
Spark Plug	Toyota	90919-01210 / SK20R11
Spark Plug	Toyota	90919-01221 / SK20BGR11
Spark Plug	Toyota	90919-01230 / SK20BR11
Spark Plug	Toyota	90919-01240 / SK16R11
Spark Plug	Toyota	90919-01235 / K20HR-U11
Spark Plug	Toyota	90919-01164 / K16R-U11
Spark Plug	Toyota	90919-01176 / K16R-U
Spark Plug	Toyota	90919-01192 / K16TR11
Spark Plug	Toyota	90919-01198 / K20TR11
Spark Plug	Toyota	90919-01170 / Q14R-U11
Spark Plug	Toyota	90919-01194 / PK20TR11
Spark Plug	Toyota	90919-01233
Spark Plug	Toyota	90919-02235 / K20HR-U11
Spark Plug	Nissan	22401-EW61C / FXE22HR11
Spark Plug	Nissan	22401-JD01B / FXE20HR11
Spark Plug	Nissan	22401-5M016 / PLFR5A-11
Spark Plug	Nissan	22401-ED815 / LZKAR6AP-11
Spark Plug	Nissan	22401-JA01B / DILKARGA-11
Spark Plug	Nissan	22401-8H515 / BKR6E-11
Spark Plug	Honda	12290-R48-H01 / NILZKR7B11
Spark Plug	Honda	12290-R62-H01 / IZFR6K11NS
Spark Plug	ENT/SUBARU IMPREZA/T	IK20
Spark Plug	ENT/SUBARU IMPREZA/T	IK16
Spark Plug		BK6REK
Spark Plug		BKR6EGP
Spark Plug	VW	04E 905 612

Spark Plug	VW	04C 905 616
Spark Plug	FoMoCo	9S7E-12405-AA
Spark Plug	Hyundai	18855-10080 / ILZK-R68
Spark Plug	Subaru	22401-AA570 / PFR5B-11
Spark Plug	Subaru	22401-AA630 / ILFR6B
Spark Plug	Subaru	22401-AA670 / SILFR6A
Spark Plug	Subaru	22401-AA731 / SILFR6A11
Spark Plug	Hyundai	ILFR5B-11
Spark Plug	Mazda	L3Y2-18-110 / ILTR5A-13G
Spark Plug	Mazda	L3Y4-18-110 / ITR6F-B
Spark Plug	Ford	SP-530 AYFS-32Y-R / ILTR5K13
Spark Plug	Ford	TR55IX
Spark Plug	Nissan/Subaru/Mazda/Hyundai/Daihatsu	K16PR-U11
		To be continued

Part Series Fit for vehicle OEM NO./Part NO.

Oil Filter	Toyota	04152-YZZA4
Oil Filter	Toyota	04152-YZZA5
Oil Filter	Toyota	04152-YZZA1
Oil Filter	Toyota	90915-03001
Oil Filter	Toyota	90915-YZZE1
Oil Filter	Toyota	90915-10001
Oil Filter	Toyota	90915-YZZD2
Oil Filter	Toyota	90915-YZZE2
Oil Filter	Toyota	90915-10002
Oil Filter	Toyota	04152-YZZA6
Oil Filter	Toyota	90915-YZZC5
Oil Filter	Toyota	90915-20001
Oil Filter	Toyota	90915-YZZJ1
Oil Filter	Nissan	15208-31U00
Oil Filter	Nissan	15208-53J00
Oil Filter	Nissan	15208-65F00

Oil Filter	Nissan	15208-ED50A
Oil Filter	Honda	15400-PLC-A01
Oil Filter	Honda	15400-RTA-004
Oil Filter	Honda	16400-41B05
Oil Filter	Honda	16400-53J10
Oil Filter	Honda	15400-PLM-A02
		To be continued

Part Series Fit for vehicle OEM NO./Part NO.

Fuel Pump	Toyota	17040-9Y00A
Fuel Pump	Honda	17040-SDC-E00
Fuel Pump	Nissan	17042-1E300
Fuel Pump	Nissan	17042-31U08
Fuel Pump	Toyota	23220-0C050
Fuel Pump	Toyota	23220-0P020
Fuel Pump	Toyota	23221-15040
		To be continued

Oxygen / Lambda Sensor / Air Fuel Ratio Sensor

Part Series	Fit for vehicle	OEM NO./Part NO.
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-12620
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-12750
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-12880
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-28320
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-29495
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-30420
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-33240
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-33380
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-33420
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-35660
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-35670
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-35680
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-39735
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-48250
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-50120
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-50130
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-60200
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-60220
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-60230

Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-28400
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-20400
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0D140
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0D150
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0K010
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-02210
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-13030
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-20690
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-26140
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-28270
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-28340
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-28400
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-28420
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-41060
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-42080
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-42150
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-44080
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-50170
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-52370
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-52380
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-53060
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-53080
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-58010

Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-58020
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-68050
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-68090
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-69175
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0D200
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0E060
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0E070
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0G010
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0G030
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0G100
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0N040
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-0P010
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-02300
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-02370
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89465-06240
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-0E070
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-0R040
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-02030
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-06150
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-28030
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-33040
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-33080
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-33090

Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-33130
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-35110
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-36010
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-48011
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-52060
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-58030
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-60010
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-60060
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-71020
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-30010
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-33040
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Toyota	89467-06060
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	226A0-4M811
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22690-40U06
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22690-ED000
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22693-JA00B
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	226A0-4L713
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	226A0-AR210
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	226A0-JA10C
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22690-2A010
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22690-2Y921
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22690-AA001
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22690-PL000

Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22693-1MR0A
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22693-EY00A
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22693-EY00B
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22693-JA10B
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Nissan	22693-JA10C
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-PAA
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-PNB
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-PNB-G02
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-PPA
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-PWA
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-R40
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-RAA-A01
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-RAC-A01
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-RCA
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-RNA
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36531-RZA
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-PAA
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-PNB
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-PWA
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-R40
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-RAA-A01
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-RAC-U01
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-RB7

Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-RFE
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Honda	36532-RNA-A01
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Mitsubishi	MN158671
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Mitsubishi	234-4741
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Mitsubishi	250-2066
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	SUZUKI	18213-66J00
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	SUZUKI	18213-63J01
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Ford	0258 006 155
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Subaru	22641-AA271
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Hyundai Kia	39210-26501
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Delphi	25325359
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Opel	90528253
Oxygen / Lambda Sensor / Air Fuel Ratio Sensor	Mazda	LFH1-188G1
		To be continued

Xenon HID Bulb / Idle Air Control Valve

Part Series	Fit for vehicle	OEM NO./Part NO.	Brand
Xenon HID Bulb		D1R	Osram/Philips
Xenon HID Bulb	Audi BMW VW Benz	D1S	Osram/Philips
Xenon HID Bulb	Toyota Nissan Hyundai	D2R / 90981-20008 / 33116-S0A-J11	Osram/Philips
Xenon HID Bulb	BMW VW Benz Citroen Ford Mazda	D2S	Osram/Philips
Xenon HID Bulb		D3R	Osram/Philips
Xenon HID Bulb	Audi	D3S	Osram/Philips
Xenon HID Bulb	Toyota	D4R / 90981-20029	Osram/Philips
Xenon HID Bulb	Toyota Honda	D4S / 90981-20013	Osram/Philips

Part Series Fit for vehicle OEM NO./Part NO. Brand

Idle Air Control Valve	Mitsubishi	1450A069	
Idle Air Control Valve	Honda	15810-PWC	
Idle Air Control Valve	Honda	15810-RAA	
Idle Air Control Valve	Honda	16022-PLC-003	
Idle Air Control Valve	Toyota	22270-0D010	
Idle Air Control Valve	Toyota	22270-11020	
Idle Air Control Valve	Toyota	22270-16060	
Idle Air Control Valve	Toyota	22270-20050	
Idle Air Control Valve	Toyota	22270-21010	
Idle Air Control Valve	Toyota	22270-28010	
Idle Air Control Valve	Toyota	22270-66010	
Idle Air Control Valve	Toyota	22270-97201	
Idle Air Control Valve	Toyota	23100-28050	
Idle Air Control Valve	Nissan	23781-4M500	
Idle Air Control Valve	Mitsubishi	MD614921	

Idle Air Control Valve	Mitsubishi	MD628166	
Idle Air Control Valve	Mitsubishi	MD628318	
		To be continued	

Parking Sensor / PDC Sensor / Bumper Sensor

Part Series	Fit for vehicle	OEM NO./Part NO.
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	08511-00340
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-0N021-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-50060
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-60040-A0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-05010
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-0N030
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-0N040
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-0N050
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-06010-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-06020-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-06030
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-12041
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-28311
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-28321-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-28460
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-28460-A0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-30010-C3
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-30010-J0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33050

Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33060
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33070
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33090
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33100
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33110-B1
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33130
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33140
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33140-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33160
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33180-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33190
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-44150-C1
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-48010
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-50011
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-50050
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-58010-A0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-58010-B6
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-58022-A0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-58030-B2
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-64010-A0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-33130-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-YY040
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-28301

Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-28330
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-28390
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-28450
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-30020
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-60050
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	89341-60317
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZD61-00016-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZD61-00017-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZD61-00002
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZ362-00201-C0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZ362-00205-K0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZ362-00208-c0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZ362-00209-G6-1
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZ362-60311-A0
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	PZ362-00201-E2
Parking Sensor / PDC Sensor / Bumper Sensor	Toyota	86790-0G010
Parking Sensor / PDC Sensor / Bumper Sensor	Nissan	25012-5E900
Parking Sensor / PDC Sensor / Bumper Sensor	Nissan	25994-2DT0A
Parking Sensor / PDC Sensor / Bumper Sensor	Nissan	25994-2DV0A
Parking Sensor / PDC Sensor / Bumper Sensor	Nissan	25994-5E900
Parking Sensor / PDC Sensor / Bumper Sensor	Nissan	25994-PA009
Parking Sensor / PDC Sensor / Bumper Sensor	Nissan	25994-PA019
Parking Sensor / PDC Sensor / Bumper Sensor	Nissan	28438-JZ00B

Parking Sensor / PDC Sensor / Bumper Sensor	Nissan	28438-KA60A-B083
Parking Sensor / PDC Sensor / Bumper Sensor	Honda	39680-TK8-A11
Parking Sensor / PDC Sensor / Bumper Sensor	Honda	39680-TL0-G01
Parking Sensor / PDC Sensor / Bumper Sensor	Honda	39685-TR0-G01
Parking Sensor / PDC Sensor / Bumper Sensor	Honda Accord	08V67-SDE-7M003
Parking Sensor / PDC Sensor / Bumper Sensor	Honda	08V67-SLG-A01
Parking Sensor / PDC Sensor / Bumper Sensor	BWM	6620 6989 069
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	6620 6989068
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	6620 9139868
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	6620 9231286
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	6620 9233037
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	6621 6938737
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	66202184263
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	66202184264
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	66200309542
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	66206989068
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	66216902182
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	6934308A102 0263003244
Parking Sensor / PDC Sensor / Bumper Sensor	BMW	66206989069
Parking Sensor / PDC Sensor / Bumper Sensor	VW	3C0 919 275 N
Parking Sensor / PDC Sensor / Bumper Sensor	VW	1J0 998 275/ 0 263003169
Parking Sensor / PDC Sensor / Bumper Sensor	VW	1J0 998 275B/ 0263003169
Parking Sensor / PDC Sensor / Bumper Sensor	VW	1T0 919 297 A
Parking Sensor / PDC Sensor / Bumper Sensor	VW, Audi	3C0 919 275 S

Parking Sensor / PDC Sensor / Bumper Sensor	VW	4H0 919 275
Parking Sensor / PDC Sensor / Bumper Sensor	VW	6QD 919 275
Parking Sensor / PDC Sensor / Bumper Sensor	VW	7L5 919 275B 0263013086
Parking Sensor / PDC Sensor / Bumper Sensor	VW	7M3 919 275 A
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	3D0 998 275A 0263003169
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	4B0 919 275 B
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	4B0 919 275 C
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	4B0 919 275 D
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	4B0 919 275 A
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	7H0 919 275 B
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	7H0 919 275 C
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	7H0 919 275 D
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	7H0 919 275 E
Parking Sensor / PDC Sensor / Bumper Sensor	Audi	7H0 919 275 A
Parking Sensor / PDC Sensor / Bumper Sensor	Buick	5482933
Parking Sensor / PDC Sensor / Bumper Sensor	Buick	5494608
Parking Sensor / PDC Sensor / Bumper Sensor	Buick	9019314
Parking Sensor / PDC Sensor / Bumper Sensor	Buick	9027347
Parking Sensor / PDC Sensor / Bumper Sensor	Buick	9049137
Parking Sensor / PDC Sensor / Bumper Sensor	Buick	9049461
Parking Sensor / PDC Sensor / Bumper Sensor	Buick	25955152
Parking Sensor / PDC Sensor / Bumper Sensor	Buick	25955153
Parking Sensor / PDC Sensor / Bumper Sensor	Mercedes-Benz	15427418

Mass Air Flow Meter/Sensor

Part Series	Fit for vehicle	OEM NO./Part NO.
Mass Air Flow Meter/Sensor	Toyota	22204-0T010
Mass Air Flow Meter/Sensor	Toyota	22204-0T040
Mass Air Flow Meter/Sensor	Toyota	22204-15010
Mass Air Flow Meter/Sensor	Toyota	22204-22010
Mass Air Flow Meter/Sensor	Toyota	22204-21010
Mass Air Flow Meter/Sensor	Toyota	22250-20020
Mass Air Flow Meter/Sensor	Toyota	22250-75010
Mass Air Flow Meter/Sensor	Toyota	22204-30010
Mass Air Flow Meter/Sensor	Toyota	22204-42011
Mass Air Flow Meter/Sensor	Toyota	22250-50060
Mass Air Flow Meter/Sensor	Toyota	22204-75030
Mass Air Flow Meter/Sensor	Toyota	22204-42010 22250-50010
Mass Air Flow Meter/Sensor	Toyota	22204-33010
Mass Air Flow Meter/Sensor	Toyota	22204-0F010
Mass Air Flow Meter/Sensor	Toyota	22250-75020
Mass Air Flow Meter/Sensor	Toyota	22250-66030
Mass Air Flow Meter/Sensor	Toyota	22204-0F030
Mass Air Flow Meter/Sensor	Toyota	22204-0D030
Mass Air Flow Meter/Sensor	Nissan	22680-AA271
Mass Air Flow Meter/Sensor	Nissan	22680-52F01
Mass Air Flow Meter/Sensor	Nissan	22680-31U05
Mass Air Flow Meter/Sensor	Nissan	22680-6N201
Mass Air Flow Meter/Sensor	Nissan	22680-6N200
Mass Air Flow Meter/Sensor	Nissan	22680-5J000
Mass Air Flow Meter/Sensor	Nissan	22680-AA310
Mass Air Flow Meter/Sensor	Nissan	22680-7S000
Mass Air Flow Meter/Sensor	Nissan	22680-31U00
Mass Air Flow Meter/Sensor	Nissan	22680-53J00
Mass Air Flow Meter/Sensor	Nissan	22680-53J01
Mass Air Flow Meter/Sensor	Nissan	22680-AD201
Mass Air Flow Meter/Sensor	Nissan	22680-AA160
Mass Air Flow Meter/Sensor	Nissan	22680-AA280
Mass Air Flow Meter/Sensor	Nissan	22680-70F05
Mass Air Flow Meter/Sensor	Nissan	22680-2J200/AFH70-14
Mass Air Flow Meter/Sensor	Nissan	AFH55M-10
Mass Air Flow Meter/Sensor	Nissan	AFH45M-46
Mass Air Flow Meter/Sensor	Nissan	22680-4M500
Mass Air Flow Meter/Sensor	Nissan	22680-6N21A
Mass Air Flow Meter/Sensor	Nissan	22680-52G00/AFH50-11

Spiral Cable Sub Assy / Clock Spring

Part Series	Fit for vehicle	OEM NO./Part NO.
Spiral Cable Clock Spring	Toyota	84306-0D021
Spiral Cable Clock Spring	Toyota	84306-0P010
Spiral Cable Clock Spring	Toyota	84306-02190
Spiral Cable Clock Spring	Toyota	84306-02200
Spiral Cable Clock Spring	Toyota	84306-06140
Spiral Cable Clock Spring	Toyota	84306-33080
Spiral Cable Clock Spring	Toyota	84306-58011
Spiral Cable Clock Spring	Toyota	84306-60080
Spiral Cable Clock Spring	Toyota	84306-0K020
Spiral Cable Clock Spring	Toyota	84306-0K021
Spiral Cable Clock Spring	Toyota	84306-0K050
Spiral Cable Clock Spring	Toyota	84306-0K051
Spiral Cable Clock Spring	Toyota	84306-52100
Spiral Cable Clock Spring	Toyota	84306-48030
Spiral Cable Clock Spring	Toyota	84306-60080
Spiral Cable Clock Spring	Toyota	84306-60071
Spiral Cable Clock Spring	Toyota	84306-60090
Spiral Cable Clock Spring	Toyota	84306-06110
Spiral Cable Clock Spring	Toyota	84306-12070
Spiral Cable Clock Spring	Toyota	84306-12100
Spiral Cable Clock Spring	Toyota	84306-22010
Spiral Cable Clock Spring	Toyota	84306-52041
Spiral Cable Clock Spring	Toyota	84306-52090
Spiral Cable Clock Spring	Toyota	84306-02190
Spiral Cable Clock Spring	Toyota	84306-06140
Spiral Cable Clock Spring	Toyota	84307-60020
Spiral Cable Clock Spring	Toyota	84307-47020
Spiral Cable Clock Spring	Toyota	B5554-3AW9A
Spiral Cable Clock Spring	Toyota	B5556-5L325
Spiral Cable Clock Spring	Toyota	84306-0E010
Spiral Cable Clock Spring	Toyota	84306-0K050
Spiral Cable Clock Spring	Toyota	84306-0N010
Spiral Cable Clock Spring	Toyota	84306-02140
Spiral Cable Clock Spring	Toyota	84306-52050
Spiral Cable Clock Spring	Toyota	84306-60050
Spiral Cable Clock Spring	Nissan	25567-EV06E
Spiral Cable Clock Spring	Nissan	25567-EB60A
Spiral Cable Clock Spring	Nissan	25567-5X00A

Spiral Cable Clock Spring	Nissan	25567-9W110
Spiral Cable Clock Spring	Nissan	25554-4M426
Spiral Cable Clock Spring	Nissan	25560-JN00A
Spiral Cable Clock Spring	Nissan	25554-VK000
Spiral Cable Clock Spring	Honda	77900-SDA-Y01
Spiral Cable Clock Spring	Honda	77900-TA0-H21
Spiral Cable Clock Spring	Honda	77900-S84-G01
Spiral Cable Clock Spring	Honda	77900-SAA
Spiral Cable Clock Spring	Honda	77900-SDA-Y31
Spiral Cable Clock Spring	Honda	77900-SNA-K02
Spiral Cable Clock Spring	Mitsubishi	8619A016
		To be continued

Auto Sensors

Part Series	Fit for vehicle	OEM NO./Part NO.
Oil Pressure Sensor	Toyota	83530-60020
Crash Sensor / Airbag sensor	Toyota	89173-0p020
Airbag sensor	Toyota	89173-06130
Speed Sensor	Toyota	89413-73010
Water Temperature Sensor	Toyota	89422-33030-89422-0H010
Throttle Position Sensor	Toyota	89452-30150
Throttle Position Sensor	Toyota	89452-33030
Knock Sensor	Toyota	89615-12040
Knock Sensor	Toyota	89615-20090
Crankshaft Position Sensor	Toyota	90919-05011
Crankshaft Position Sensor	Toyota	90919-05012
Crankshaft Position Sensor	Toyota	90919-05016
Crankshaft Position Sensor	Toyota	90919-05017
Crankshaft Position Sensor	Toyota	90919-05026
Crankshaft Position Sensor	Toyota	90919-05030
Crankshaft Position Sensor	Toyota	90919-05035
Crankshaft Position Sensor	Toyota	90919-05045
Crankshaft Position Sensor	Toyota	90919-05057
Crankshaft Position Sensor	Toyota	90919-05059
Crankshaft Position Sensor	Toyota	90919-05060
Crankshaft Position Sensor	Toyota	90919-05067
Crankshaft Position Sensor	Toyota	90919-05070
Crankshaft Position Sensor	Toyota	90919-A5003
Oil Pressure Sensor	Toyota	83530-28020
Oil Pressure Sensor	Toyota	83530-60020
Turn Signal Switch	Toyota	84632-34011
Accelerator Unit	Toyota	89441-5290B
Throttle Position Sensor	Toyota	89452-52011
Fuel Tank Pressure Sensor	Toyota	89461-35010
Knock Sensor	Toyota	89615-20060
Crankshaft Position Sensor	Toyota	90919-05002
Crankshaft Position Sensor	Toyota	90919-05007
Crankshaft Position Sensor	Toyota	90919-05043
Crankshaft Position Sensor	Toyota	90919-05045
Crankshaft Position Sensor	Toyota	90919-05061
Camshaft Position Sensor	Toyota	90919-A5004
Oil Pressure Sensor	Toyota	83530-60030
Oil Pressure Sensor	Toyota	83530-60040

Reverse Light Switch	Toyota	84210-04010
Throttle Position Sensor	Toyota	22030-28011
Tire Pressure Sensor	Toyota	42607-0C050
Tire Pressure Sensor	Toyota	42607-0C060
Tire Pressure Sensor	Toyota	42607-0C070
Parking Brake Switch	Toyota	84550-33010
Transmission Revolution Sensor	Toyota	89413-32010
Transmission Revolution Sensor	Toyota	89413-33030
Throttle Position Sensor	Toyota	89452-22090
Throttle Position Sensor	Toyota	89452-97401
Camshaft Position Sensor	Toyota	90919-05036
Camshaft Position Sensor	Toyota	90919-05054
Water Temperature Sensor	Toyota	89422-16010
Water Temperature Sensor	Toyota	89422-20010
Water Temperature Sensor	Toyota	89422-35010
Throttle Position Sensor	Nissan	22620-31U01
Crankshaft Position Sensor	Nissan	23731-31U10
Crankshaft Position Sensor	Nissan	23731-35U10
Knock Sensor	Nissan	22060-2A000
Knock Sensor	Nissan	22060-30P00
Crankshaft Position Sensor	Nissan	23731-3S500
Camshaft Position Sensor	Nissan	23731-6J906 / A29-640
Crankshaft Position Sensor	Nissan	23731-6N21A
Crankshaft Position Sensor	Nissan	23731-AL606
Crankshaft Position Sensor	Nissan	23731-AL616
Crankshaft Position Sensor	Nissan	23731-ED01A
Camshaft Position Sensor	Nissan	23731-ED02A
Speed Sensor	Nissan	31935-1XF00
Speed Sensor	Nissan	31935-1XF01
Speed Sensor	Nissan	31935-8E006
Speed Sensor	Nissan	31935-8E007
Throttle Position Sensor	Nissan	SERA483-06
A/C Pressure Sensor	Nissan	92136-6J001
Crash Sensor / Airbag sensor	Nissan	98581-CD000
Throttle Position Sensor	Nissan	SERA484-23
Throttle Position Sensor	Nissan	A22-669B00
Oil Pressure Sensor	Nissan	25240-2DT0A
Camshaft Position Sensor	Honda	37510-PNB-003
Camshaft Position Sensor	Honda	37840-plc-006
Knock Sensor	Honda	30530-P5M-013
Crankshaft Position Sensor	Honda	37500-RAA-A01
Crankshaft Position Sensor	Honda	37510-RAA
Manifold Air Pressure Sensor(MAP Sensor)	Honda	37830-PGK-A01
Camshaft Position Sensor	Mitsubishi	MD327107

Crankshaft Position Sensor	Mitsubishi	J5T20171A
Crankshaft Position Sensor	Mitsubishi	MD303088
Throttle Position Sensor	Ford	6L2E-9E928-AA
Accelerator Unit	Mazda	CB05-41-AC0
Crankshaft Position Sensor	Mazda	J5T27072
Manifold Air Pressure Sensor(MAP Sensor)	Suzuki	18590-79F00
		To be continued

Cam Timing Oil Control Valve Assy

Part Series	Fit for vehicle	OEM NO./Part NO.
Cam Timing Oil Control Valve Assy	Toyota	15330-20011
Cam Timing Oil Control Valve Assy	Toyota	15330-22030
Cam Timing Oil Control Valve Assy	Toyota	15330-31020
Cam Timing Oil Control Valve Assy	Toyota	15330-75010
Cam Timing Oil Control Valve Assy	Toyota	15340-31020
Cam Timing Oil Control Valve Assy	Toyota	15330-37010
Cam Timing Oil Control Valve Assy	Toyota	15330-37020
Cam Timing Oil Control Valve Assy	Toyota	15330-38010
Cam Timing Oil Control Valve Assy	Toyota	15330-0Y010
Cam Timing Oil Control Valve Assy	Toyota	15330-0Y020
Cam Timing Oil Control Valve Assy	Toyota	15330-31010
Cam Timing Oil Control Valve Assy	Toyota	15330-31020
Cam Timing Oil Control Valve Assy	Toyota	15330-31030
Cam Timing Oil Control Valve Assy	Toyota	15330-46010
Cam Timing Oil Control Valve Assy	Toyota	15330-74010
Cam Timing Oil Control Valve Assy	Toyota	15330-75010
Cam Timing Oil Control Valve Assy	Toyota	15330-97402
Cam Timing Oil Control Valve Assy	Toyota	15340-31010
Cam Timing Oil Control Valve Assy	Nissan	23796-EA200
Cam Timing Oil Control Valve Assy	Nissan	23796-EA205
Cam Timing Oil Control Valve Assy	Nissan	23796-ED000
Cam Timing Oil Control Valve Assy	Nissan	23796-EN200
Cam Timing Oil Control Valve Assy	Nissan	23796-JA00A
Cam Timing Oil Control Valve Assy	Nissan	23796-JA10B
Cam Timing Oil Control Valve Assy	Nissan	23796-ZE00C
Cam Timing Oil Control Valve Assy	Honda	15830-RBB
Cam Timing Oil Control Valve Assy	Honda	15810-RNA-A01
		To be continued

Auto Switches

Part Series	Fit for vehicle	OEM NO./Part NO.
Power Window Lifter Switch	Toyota	84030-0N011
Power Window Lifter Switch	Toyota	84030-0P011
Power Window Lifter Switch	Toyota	84040-0N020
Power Window Lifter Switch	Toyota	84040-0P011
Power Window Lifter Switch	Toyota	84810-0N010
Power Window Lifter Switch	Toyota	84810-06060
Power Window Lifter Switch	Toyota	84810-12080
Power Window Lifter Switch	Toyota	84820-06100
Power Window Lifter Switch	Toyota	84820-12480
Power Window Lifter Switch	Toyota	84820-33170
Power Window Lifter Switch	Toyota	84820-0K050
Power Window Lifter Switch	Toyota	84820-12340
Power Window Lifter Switch	Toyota	84820-26201
Power Window Lifter Switch	Toyota	84820-26211
Power Window Lifter Switch	Toyota	84820-33180
Power Window Lifter Switch	Toyota	84820-35020
Power Window Lifter Switch	Toyota	84820-60090
Turn Signal Switch	Toyota	84140-12520
Turn Signal Switch	Toyota	84140-12530
Steering Wheel Switch	Toyota	84250-06160
Neutral Safety Switch	Toyota	84540-0E010
Neutral Safety Switch	Toyota	84540-33010
Neutral Safety Switch	Toyota	84540-46010
Neutral Safety Switch	Toyota	84540-12230
Neutral Safety Switch	Toyota	84540-16040
Neutral Safety Switch	Toyota	84540-30320
Neutral Safety Switch	Toyota	84540-35050
Neutral Safety Switch	Toyota	84540-48010
Neutral Safety Switch	Toyota	84540-51010
Neutral Safety Switch	Toyota	84540-52040
Neutral Safety Switch	Toyota	84540-52050
Neutral Safety Switch	Toyota	84540-60050
Neutral Safety Switch	Toyota	84540-71010
Ignition Switch	Toyota	84450-52010
Ignition Switch	Toyota	84450-60180
Ignition Switch	Toyota	84450-12200
Ignition Switch	Toyota	84450-52010
Neutral Safety Switch	Nissan	31918-1XF00

Neutral Safety Switch	Nissan	31918-1XK0A
Neutral Safety Switch	Nissan	31918-3AX01
Power Window Lifter Switch	Honda	35750-TMO-F01
	To be continued	

